

OPERATING INSTRUCTIONS

Dia-Glo™ M - Marble surfaces

A white polyester buffing pad works best with this compound. However, you may also use natural fiber or felt pads.

1. Always work with small areas (50 ft²) until you are familiar with the product.
2. Sprinkle 1/2 cup of Dia-Glo™ compound on the stone and work it together with 4 oz (1/2 cup) of water to dissolve the compound.
3. The consistency of the dissolved compound should remain milky throughout buffing process (tending more toward a liquid than a paste). Add a little water if necessary.
4. Begin by buffing for 3 to 5 minutes over the entire work area.
5. Using a squeegee, periodically inspect the stone for the desired level of shine. Repeat buffing until satisfied.
6. IMMEDIATELY vacuum the stone until dry and rinse with clean water which neutralizes any residue. DO NOT let it stand.
7. Buff the finished area with a clean dry white pad.

Hint

You may find that the leftover marble compound is reusable. Continue using it until it no longer performs adequately. This will save you money, and generate less waste in the environment.

NOTICE

While in the container, Dia-Glo™ M buffing compound tends to absorb ambient moisture present in the air. This will cause the product to form clumps, but will in no way affect its performance. Use as normal if this occurs.

Dia-Glo™ D & L - Granite surfaces

A felt buffing pad works best with this compound. Never use a polyester pad on granite surfaces.

1. Always work with small areas (50 ft²) until familiar with the product.
2. Sprinkle 1/2 cup of Dia-Glo™ compound on the stone and work it together with a little (1 oz.) water to dissolve the compound.
3. The consistency of the buffing compound should remain wet and almost paste like.
4. Begin by buffing for approx 10 to 15 minutes over entire work area.
5. The consistency of the compound can be controlled by adding very small quantities of water while buffing. You should be able to feel good resistance to the rotating machine (without drying the stone surface) for the best results.
6. Using a squeegee, periodically inspect the stone for the desired level of shine. Repeat buffing until satisfied.
7. Vacuum the stone until dry. Mop the polished area with clean water and dry again.

SAFETY

Always wear protective clothing such as safety glasses, gloves and footwear. Do not modify equipment and follow the recommended safety procedures of the machinery manufacturer. Do not operate power tools without their guards or shields.