



HYDRO BAN[®] XP

DS-36642-0521

**Globally Proven
Construction Solutions**

1. PRODUCT NAME

HYDRO BAN[®] XP

2. MANUFACTURER

LATICRETE International, Inc.
1 LATICRETE Park North
Bethany, CT 06524-3423 USA

Telephone: +1.203.393.0010, ext. 1235
Toll Free: 1.800.243.4788, ext. 1235
Fax: +1.203.393.1684
Website: laticrete.com

3. PRODUCT DESCRIPTION

HYDRO BAN XP is a thin, load bearing waterproofing/crack isolation membrane with extreme performance. HYDRO BAN XP is specifically designed to handle a wide variety of environmental/substrate conditions, such as substrate temperatures as low as 32°F (0° C) and also be used in steam showers and steam rooms. HYDRO BAN XP does not require the use of fabric in the field, coves or corners. HYDRO BAN XP is a single component self-curing liquid rubber polymer that forms a flexible, seamless waterproofing membrane. HYDRO BAN XP bonds directly to a wide variety of substrates. Equipped with Microban[®] Protection

Uses

- Interior and exterior
- Swimming pools, fountains and water features
- Shower pans, stalls and tub surrounds
- Steam rooms and steam showers
- Industrial, commercial and residential bathrooms and laundries
- Spas and hot tubs
- Kitchens and food processing areas
- Terraces and balconies over unoccupied spaces
- Countertops and facades

Advantages

- Allow for flood testing in 2 hours at 70°F (21°C) or higher (Refer to cautions section for more information on curing)

- Does not require the use of fabric (For gaps 1/8" (3 mm) or less see DS 663.5 for complete instructions)
- Anti-fracture protection of up to 1/8" (3 mm) over shrinkage and other non-structural cracks
- Thin; only 0.020–0.030" (0.5–0.8 mm) thick when cured
- Exceeds ANSI A118.10 and A118.12
- IAPMO PS106 approved
- PVC and ABS plumbing fixtures only
- "Extra Heavy Service" rating per TCNA performance levels (RE: ASTM C627 Robinson Floor Test)
- Changes in color from a light sage to an olive green when cured
- Equipped with Microban(R) technology to protect the treated article
- Bonds directly to metal, ABS, PVC and various other common materials
- Color changing technology for ease of inspection and cure time notification
- No solvents and non-flammable

Suitable Substrates

- Cement Backer Board
- Cement Mortar Bed
- Cement Plaster
- Cement Terrazzo
- Concrete
- Concrete and Brick Masonry
- Poured Gypsum Underlayment
- Self-Leveling and Patching Compounds
- Exterior Glue Plywood (Interior Only)
- Gypsum Wallboard
- Ceramic Tile and Stone
- Gypsum Wallboard (Interior use only, non-wet areas)
- Gypsum Plaster (Interior use only, non-wet areas)

Packaging

Packaging 1 Gallon - 4 x 1 gal (3.8 L) pails of liquid packed in a carton (30 cartons/pallet)

5 Gallon - (18.9 L) pail liquid (36 commercial units/pallet)

275 Gallon - (1041 L) 1 Tote

Coverage

1 Gallon - 50 ft² (4.6 m²)

5 Gallon - 250 ft² (23.2 m²)

275 Gallon - 68,750 ft² (6,387 m²)

Approximate Coverage Coverage

1 Gallon - 50 ft² (4.6 m²)

5 Gallon - 250 ft² (23.2 m²)

275 Gallon - 68,750 ft² (6,387 m²)

Shelf Life

Factory sealed containers of this product are guaranteed to be of first quality for two (2) years if stored at temperatures >32°F (0°C) and <110°F (43°C).>

Limitations

- DO NOT bond to OSB, particle board, interior glue plywood, luan, Masonite® or hardwood surfaces.
- Adhesives/mastics, mortars and grouts for ceramic tile, pavers, brick and stone are not replacements for waterproofing membranes. When a waterproofing membrane is required, use HYDRO BAN® XP.
- Do not use as a primary roofing membrane over occupied space. For more information in installation of tile over wood decks, or, over occupied or finished spaces please refer to TDS 157 "Exterior Installation of Tile and Stone Over Occupied Space."
- Do not use over dynamic expansion joints, structural cracks or cracks with vertical differential movement (See HYDRO BAN XP Installation Instructions, DS-663.5 for complete instructions).
- The installation of Waterproofing Membranes in submerged applications must be installed in a manner that creates a continuous "waterproof pan effect" without voids or interruptions. Therefore, applying waterproofing membranes in limited areas (e.g. solely at the waterline) in submerged applications is not recommended.
- Do not use over cracks >1/8" (3 mm) in width.
- Do not expose unprotected membrane to sun or weather for more than 30 days.
- Do not expose to negative hydrostatic pressure, excessive vapor transmission, rubber solvents or ketones.
- Must be covered with ceramic tile, stone, brick, dry pack thick bed mortar beds (non-submerged applications), terrazzo or other traffic-bearing finish. Use protection board for temporary cover.
- Obtain approval by local building code authority before using product in shower pan applications.
- Follow all applicable local building code having jurisdiction.
- Do not install directly over single layer wood floors, plywood tubs/showers/fountains or similar constructs.
- Not for use beneath cement or other plaster finishes. Consult with plaster manufacturer for their recommendations when waterproofing membrane is required under plaster finishes.
- Not for use under self-leveling underlayments or decorative wear surfaces.

- Surfaces must be structurally sound, stable and rigid enough to support ceramic/stone tile, thin brick and similar finishes.
- Substrate deflection under all live, dead and impact loads, including concentrated loads, must not exceed L/360 for thin bed ceramic tile/brick installations or L/480 for thin bed stone installations and L/600 for all exterior veneer applications where L=span length.

Cautions

- Consult SDS for safety information.
- Allow membrane to cure fully (typically 24 hours at 32°F – 69°F (0°C – 21°C) and 70% RH and 2 hours at 70°F (21°C) or higher and 50% RH before flood testing); flood test prior to applying tile or stone.
- Maximum amount of moisture in the concrete substrate should not exceed 5 lbs/1,000 ft² (283 µg/s m²)/24 hrs per ASTM F-1869 or 75% relative humidity per ASTM F-2176 as measured with moisture probes.
- During cold weather, protect finished work from traffic until fully cured.
- For white and light-colored marbles, use a white Latex Portland Cement Thin Set Mortar.
- For green and moisture sensitive marble, agglomerates and resin backed tile and stone use LATAPOXY® 300 Adhesive (refer to DS-633).
- Wet coat thickness is 0.015 to 0.022" (0.4 to 0.6 mm) per coat. Use a wet film thickness gauge to check thickness.
- Allow wet mortars to cure for 72 hours at 70°F (21°C) prior to installing HYDRO BAN XP. Allow HYDRO BAN XP a minimum 2 hours cure at 70°F (21°C) prior to flood testing in these conditions.
- Protect from exposure to traffic or water until fully cured.
- HYDRO BAN XP will go from a light green to a dark green when fully cured. The second coat should not be applied until the first coat is fully cured. All flood test times should be after the second coat is fully cured with no light sage areas showing.
- After second coat is applied at 70°F (21°C) and 50% RH. The time to tile will vary depending on substrate, temperature and relative humidity.
- Sanding or screening may be needed when installing over mortar beds or self-leveling underlayments to remove laitance, loose material, etc.

4. TECHNICAL DATA





Substrate	Time to Tile (min.)****
Concrete	50
Cement Board	30
Fiber Cement Underlayment	15

The data in the above table shall be used by the Project Design Professional to determine suitability, placement, building code conformance and over-all construct appropriateness of a given installation assembly.

VOC/LEED Product Information

This product has been certified for Low Chemical Emissions (ULCOM/GG UL2818) under the UL GREENGUARD Certification Program. For Chemical Emissions. For Building Materials, Finishes and Furnishings (UL 2818 Standard) by UL Environment.

Approvals

- ICC Evaluation Service report ESR-2417
- IAPMO/Uniform Plumbing Code File No.3524
- Los Angeles Board of Building and Safety Commissioners File Number: M-070162
- City of Philadelphia Plumbing Adviser board Case Number:4624
- City of Tampa Construction Services Division
- Commonwealth of Massachusetts Board of State Examiners of Plumbers and Gasfitters

Applicable Standard

- ANSI A118.10 and A118.12
- IAPMO PS106
- ICC Evaluation Service report ESR-2417
- IAPMO/Uniform Plumbing Code File No.3524
- Los Angeles Board of Building and Safety Commissioners File Number: M-070162
- City of Philadelphia Plumbing Adviser board Case Number:4624
- City of Tampa Construction Services Division
- Commonwealth of Massachusetts Board of State Examiners of Plumbers and Gasfitters
- Miami Dade NOA

Physical Properties

****After second coat is applied at 70°F (21°C) and 50% RH. The time to tile will vary depending on substrate, temperature and relative humidity.

Physical Property	Test Method	HYDRO BAN® XP
7-day Hydrostatic Test	ANSI A118.10	Pass
7-day Breaking Strength	ANSI A118.10	265–300 psi (1.8–2.1 MPa)
7-day Water Immersion	ANSI A118.10	95–120 psi (0.7–0.8 MPa)
7-day Shear Bond	ANSI A118.10	200–275 psi (1.4–1.9 MPa)
28-day Shear Strength	ANSI A118.10	215–345 psi (1.5–2.3 MPa)
System Crack Resistance Test	ANSI A118.12.5.4	Pass (High)
Water Vapor Transmission	ASTM E 96–00E1 Procedure B	0.515 grains/h • ft ² (0.3602 g/h • m ²)
Water Vapor Permeance	ASTM E 96–00E1 Procedure B	1.25 perms 71.21 (ng/Pa • s • m ²)
Water Vapor Permeance	ASTM E 96 Procedure E	0.19 perms
System Performance	ANSI A118.10; ASTM C627; TCA Rating	cycles 1–14 "Extra Heavy"
Potability of Water Applicable to Waterproofing Systems	NBR 12170:2009 (Technical Norm from Brazil)	Pass
Tensile Strength for Elongation		250%
Thickness (Dried)		20–30 mils (0.5–0.8 mm)

Working Properties

Working Properties

HYDRO BAN® XP can be applied using a paint brush, roller or trowel. All areas must have two coats to ensure waterproofing capabilities. When using a paint roller, substrate will not show through HYDRO BAN XP if coated with 0.020 – 0.030" (0.5 – 0.8 mm) of dried membrane. Color changes from a light green to dark green when fully cured.

Specifications subject to change without notification. Results shown are typical but reflect test procedures used. Actual field performance will depend on installation methods and site conditions.

5. INSTALLATION

• Working Properties

HYDRO BAN® XP can be applied using a paint brush, roller or trowel. All areas must have two coats to ensure waterproofing capabilities. When using a paint roller, substrate will not show through HYDRO BAN XP if coated with 0.020 – 0.030" (0.5 – 0.8 mm) of dried membrane. Color changes from a light green to dark green when fully cured. Refer to DS 663.5 for complete installation instructions prior to using product

Surface Preparation

Surface temperature must be 32°F – 90°F (0 – 32°C) during application and for 24 hours after installation. All substrates must be structurally sound, clean and free of dirt, oil, grease, paint, laitance, efflorescence, concrete sealers or curing compounds. Make rough or uneven concrete smooth to a wood float or better finish with a underlayment. Do not level with asphalt based products. Maximum deviation in plane must not exceed 1/4" in 10 ft (6 mm in 3 m) with no more than 1/16" in 1 ft (1.5 mm in 0.3 m) variation between high spots. Dampen hot, dry surfaces and sweep off excess water— installation may be made on a damp surface. See DS 663.5 for information on installation over concrete.

1. Surfaces must be structurally sound, stable and rigid enough to support ceramic/stone tile, thick brick and similar finishes. Installer must verify that deflection under all live, dead and impact loads of interior plywood floors does not exceed industry standards of L/360 for ceramic tile and brick or L/480 for stone installations and L/600 for all exterior veneer applications where L=span length.

2. Minimum construction for interior plywood floors. **SUBFLOOR:** 5/8" (15 mm) thick exterior glue plywood, either plain with all sheet edges blocked or tongue and groove, over bridged joints spaced 16" (400 mm) o.c. maximum; fasten plywood 6" (150 mm) o.c. along sheet ends and 8" (200 mm) o.c. along intermediate supports with 8d ring-shank, coated or hot dip galvanized nails (or screws); allow 1/8" (3 mm) between sheet ends and 1/4" (6 mm) between

sheets edges; all sheet ends must be supported by a framing member; glue sheets to joints with construction adhesive.

UNDERLAYMENT: 5/8" (15 mm) thick exterior glue plywood fastened 6" (150 mm) o.c. along sheet ends and 8" (200 mm) o.c. in the panel field (both directions) with 8d ring-shank, coated or hot dip galvanized nails (or screws); allow 1/8" (3 mm) to 1/4" (6 mm) between sheets and 1/4" (6 mm) between sheet

edges and any abutting surfaces; offset underlayment joints from joints in subfloor and stagger joints between sheet ends; glue underlayment to subfloor with construction adhesive. Refer to Technical Data Sheet 152 "Bonding Ceramic Tile, Stone or Brick Over Wood Floors" for complete details.

Bonding to TCNA Compliant Poured Gypsum

Underlayment Poured gypsum-based underlayments must meet TCNA requirements for compressive strength and the performance requirements of ASTM C627 for the anticipated service level designated by the design professional. Poured gypsum underlayment thickness and application varies, consult the manufacturer for specific recommendations. The underlayment must be dry and properly cured following the manufacturer's recommendations to achieve a permanent installation. Surfaces to be covered must be clean, structurally sound and meet the maximum allowable deflection standard of L/360 for ceramic tile and L/480 for stone under total anticipated load. Expansion joints must be installed in accordance with ANSI/TCNA guidelines. Prime all surfaces to receive HYDRO BAN XP with properly applied manufacturer's sealer or with a primer coat of HYDRO BAN XP, consisting of 1 part HYDRO BAN XP, diluted with 4 parts clean, cool tap water. In a clean pail, mix at low speed to obtain a homogeneous solution. The primer can be brushed, rolled or sprayed to achieve an even coat. Apply the primer coat to the floor at a rate of 250 to 300 ft²/gallon (6.1 to 7.5 M²/L) of diluted HYDRO BAN XP. Allow the primer coat to dry completely (approximately 24 hrs., depending on substrate and air temperature and humidity). When dry apply two full coats of HYDRO BAN XP to the primed area following the guidelines in this data sheet and DS-1216 HYDRO BAN XP Installation Instructions.

Pre-Treat Cracks & Joints

Fill all substrate cracks, cold joints, and control joints to a smooth finish using a Latex Fortified Thin-Set. Alternatively, a liberal coat^{^^} of HYDRO BAN XP applied with a paint brush or trowel may be used to fill in non-structural joints and cracks. Apply a liberal coat^{^^} of HYDRO BAN XP approximately 8" (200 mm) wide over

substrate cracks, cold joints, and control joints using a paint brush or roller (heavy napped roller cover). 6" (150 mm) Waterproofing/Anti-Fracture Fabric can be used to pretreat cracks, joints, curves, corners, drains and penetrations with HYDRO BAN XP.

Pre-Treat Coves and Floor/Wall Transitions

Fill all substrate coves and floor/wall transitions to a smooth finish and changes in plane using a latex fortified thin-set mortar. Alternatively, a liberal coat^{^^} of HYDRO BAN XP applied with a paint brush or trowel may be used to fill in cove joints and floor/wall transitions <1/8" (3 mm). Apply a liberal coat^{^^} of HYDRO BAN XP approximately 8" (200 mm) wide over substrate coves and floor/wall transitions using a paint brush or roller (heavy napped roller cover).

Pre-Treat Drains

Drains must be of the bonding flange or clamping ring type, with weepers and as per ASME A112.6.3. Apply a liberal coat^{^^} of HYDRO BAN XP Waterproofing Membrane liquid around and over the bonding flange or the bottom half of drain clamping ring. Cover with a second coat^{^^} of HYDRO BAN XP. When dry, apply a LATASIL™ bead where the HYDRO BAN XP meets the drain throat. Install top half of drain clamping ring.

Pre-Treat Penetrations

Allow for a minimum 1/8" (3 mm) space between drains, pipes, lights or other penetrations and surrounding ceramic tile, stone or brick. Pack any gaps around pipes, lights or other penetrations with a Latex fortified thin-set mortar. Apply a liberal coat^{^^} of HYDRO BAN XP liquid around penetration opening. Cover with a second coat^{^^} of HYDRO BAN XP. Bring HYDRO BAN XP up to level of tile or stone. When dry, seal flashing with LATASIL. Crack Isolation (Partial Coverage) Crack suppression must be applied a minimum of 3 times the width of the tile or stone being installed. The tile installed over the crack cannot be in contact with the concrete.

Follow TCNA Method F125 for the treatment of hairline cracks, shrinkage cracks, and saw cut or control joints: Apply a liberal coat^{^^} of HYDRO BAN XP to a minimum of three (3) times the width of the tile using a paint roller or paint brush and allow to dry. After the first coat has dried to the touch, install a second liberal coat^{^^} of HYDRO BAN XP over the first coat.

As an alternative; Apply a liberal coat^{^^} of HYDRO BAN XP liquid, 3 times the width of the tile over the crack using a paint roller or paint brush and immediately apply the 6" (150mm) wide Waterproofing/Anti-Fracture Fabric into the wet liquid over the crack. Press firmly with brush or roller to allow complete "bleed through" of liquid. Immediately apply another liberal coat^{^^}

of HYDRO BAN XP liquid over the fabric and allow to dry. When the first treatment has dried, apply a liberal coat^{^^} of HYDRO BAN XP to over the first wide coat, using a paint roller or paint brush, and allow to dry. Treat closest joint to the crack, saw cut, or cold joint in the tile or stone installation with LATASIL.

^{^^} Wet coat thickness is 15 – 22 mils (0.4 – 0.6 mm) consumption per coat is -0.01/gal/ft² (-0.4m²/L); coverage per coat is – 100 ft²/gal (-2.5m²/L). Use wet film gauge to check thickness.

Main Application

Allow any pre-treated areas to dry to the touch. Apply a liberal coat^{^^} of HYDRO BAN XP with brush or roller over substrate including pre-treated areas. Apply another liberal coat^{^^} of HYDRO BAN XP over the first coat of HYDRO BAN XP. Let topcoat dry to the touch, approximately 1–2 hours at 70°F (21°C) and 50% RH. When last coat has dried to the touch, inspect final surface for pinholes, voids, thin spots or other defects. HYDRO BAN XP will dry to a dark green color when it's dry to touch. Use additional HYDRO BAN XP to seal defects.

Movement Joints

See HYDRO BAN Installation Instructions DS-663.5.

Note: Apply a liberal coat^{^^} of HYDRO BAN XP, approximately 8" (200 mm) wide over the areas. Then embed and loop the 6" (150 mm) wide Waterproofing/Anti-Fracture Fabric and allow to bleed through. Then top coat with a second coat^{^^} of HYDRO BAN XP.

Protection

Provide protection for newly installed membrane, even if covered with a thin bed ceramic tile, stone or brick installation, against exposure to rain or other water for a minimum of 2 hours at 70°F (21°C) and 50% RH.

Flood Testing

Allow membrane to cure fully before flood testing, typically 2 hours after final cure at 70°F (21°C) and 50% RH. Cold and/or wet conditions will require a longer curing time. For temperatures 32°F – 69°F (0 – 21°C) allow 24 hours after final cure prior to flood testing.

Installing Finishes

Once HYDRO BAN XP has dried to the touch, ceramic tile, stone or brick may be installed by the thin bed method with a Latex Thin-Set Mortar. Allow HYDRO BAN XP to cure 2 hours at 70°F (21°C) and 50% RH before covering with, thick bed mortar, epoxy adhesives, terrazzo or moisture sensitive resilient or wood flooring. Do not use solvent-based adhesives directly on HYDRO BAN XP.

Drains & Penetrations

Use LATASIL and foam backer rod to seal space between drain or penetration and finish. Do not use a grout or joint filler mortar.

Control Joints

Ceramic tile, stone and brick installations must include sealant- filled joints over any control joints in the substrate. However, the sealant-filled joints can be offset horizontally by as much as one tile width from the substrate control joint location to coincide with the grout joint pattern.

Movement Joints

Ceramic tile, stone and thin brick installations must include expansion at coves, corners, other changes in substrate plane and over any expansion joints in the substrate. Expansion joints in ceramic tile, stone or brickwork are also required at perimeters, at restraining surfaces, at penetrations and at the intervals described in the Tile Council of North America, Inc. (TCNA) Handbook Installation Method EJ171. Use LATASIL and backer rod.

Spray Application of HYDRO BAN[®] XP

Follow all installation and surface preparation requirements outlined in this document and DS 663.5.

The sprayer being used for the application of HYDRO BAN XP should be capable of producing a maximum of 3300 psi (22.8 MPa) with a flow rate of 0.95 to 1.6 GPM (3.6 to 6.0 LPM) using a 0.521 or a 0.631 reversible tip. Keep the unit filled with HYDRO BAN XP to ensure continuous application of liquid. The hose length should not exceed 100' (30 m) in length and 3/8" (9 mm) in diameter.

Apply a continuous HYDRO BAN XP film with an overlapping spray^{^^}. The wet film has a light green appearance and dries to a dark green color. When the first coat has dried to a uniform olive green color, approximately 45 to 90 minutes at 70°F (21°C), visually inspect the coating for any voids or pinholes. Fill any defects with additional material and apply the second coat^{^^} at right angles to the first. The wet film thickness should be checked periodically using a wet film gauge. Each wet coat should be 0.015 – 0.022 inches (0.4 – 0.6 mm) thick. The combined dried coating should be 0.020 – 0.030 inches (0.5 – 0.8 mm) thick.

Check application thickness with a wet film gauge periodically as the HYDRO BAN XP is being dispensed to ensure that the appropriate thickness and coverage is achieved. Bounce back and overspray will consume more product. To achieve the required film thickness, the coating must be free from pinholes and air bubbles. Do not back roll the spray applied coating. Allow the HYDRO BAN to cure in accord with the instructions in this document, DS 663.5 and TDS 410 prior to the installation of the tile or stone finish.

It is important to note that areas not scheduled to receive the HYDRO BAN XP should be taped off and protected from any potential overspray. Expansion and movement joints should be honored and treated as outlined in this document, DS-663.5 and TDS 410.

^^ Wet coat thickness is 15 – 22 mils (0.4 – 0.6 mm) consumption per coat is -0.01/gal/ft² (-0.4m²/L); coverage per coat is – 100 ft²/gal (-2.5m²/L). Use wet film gauge to check thickness.

6. AVAILABILITY AND COST

Availability

LATICRETE materials are available worldwide.

For Distributor Information, Call:

Toll Free: 1.800.243.4788

Telephone: +1.203.393.0010

For on-line distributor information, visit LATICRETE at laticrete.com

Cost

Contact a LATICRETE Distributor in your area.

7. WARRANTY

See 10. FILING SYSTEM:

- DS 025.0: 25 Year System Warranty
- DS 230.10: 10 Year System Warranty
- DS 230.13: 1 Year Product Warranty
- DS 230.15APD: LATICRETE 15 Year Tile & Stone System Warranty
- DS 230.99: LATICRETE Lifetime System Warranty (United States and Canada)

8. MAINTENANCE

Non-finish LATICRETE and LATAPOXY installation materials require no maintenance but installation performance and durability may depend on properly maintaining products supplied by other manufacturers.

9. TECHNICAL SERVICES

Technical Assistance

Information is available by calling the LATICRETE Technical Service Hotline:

Toll Free: 1.800.243.4788, ext. 1235

Telephone: +1.203.393.0010, ext. 1235

Fax: +1.203.393.1948

Technical and Safety Literature

To acquire technical and safety literature, please visit our website at laticrete.com.

10. FILING SYSTEM

Additional product information is available on our website at laticrete.com. The following is a list of related documents:

- DS 230.13: LATICRETE Product Warranty
- DS 230.05: LATICRETE 5 Year System Warranty (United States and Canada)
- DS 230.15: LATICRETE 15 Year System Warranty for Steel or Wood Framed Exterior Facades (United States and Canada)
- DS 025.0: LATICRETE 25 Year System Warranty (United States and Canada)
- DS 230.99: LATICRETE Lifetime System Warranty (United States and Canada)
- DS 633.0: LATAPOXY 300 Adhesive
- DS 663.5: HYDRO BAN™ XP Installation Instructions
- DS 6200.1: LATASIL™
- TDS 152: “Bonding Ceramic Tile, Stone or Brick Over Wood Floors”
- TDS 410: Spraying HYDRO BAN
- TDS 157: “Exterior Installation of Tile and Stone Over Occupied Space.”

LATICRETE International, Inc.

One LATICRETE Park North, Bethany, CT 06524-3423 USA • 1.800.243.4788 • +1.203.393.0010 • www.laticrete.com

© 2021 LATICRETE International, Inc. All trademarks shown are the intellectual properties of their respective owners.