



THE ORIGINAL  
GRANITE BRACKET

# SIDE WALL

C O U N T E R T O P   S U P P O R T   B R A C K E T

**The Side Wall Bracket is designed to attach to the side of the cabinet.**



**THE ORIGINAL  
GRANITE BRACKET®**

originalgranitebracket.com  
888-584-1112

#### **WATCH OUR INSTALLATION VIDEO**

<https://originalgranitebracket.com/pages/installation-videos>

#### **SAFETY INSTRUCTIONS**

- Use the correct tools.
- Wear safety goggles & proper safety equipment.
- Follow fixture, power tools & paint manufactures instructions & user manuals.
- Use common sense & follow good construction practices.
- Consult a professional when installing brackets for load bearing application.
- Be sure the bracket has a substructure that is able to support the bracket & any other additional weight that may be added to it.
- When in doubt, consult a professional installer.

## **Installation Guide:**

### **Step #1:**

Start by cutting a 2.5" wide by 0.5" deep "pocket" next to the side wall of the cabinet.

### **Step #2:**

Once the "pocket" is made, simply insert the Side Wall Countertop Support Bracket & attach it using the pre-drilled screw holes & appropriate wood screws.

**NOTE:** We have provided screws *HOWEVER* make sure the length of the provided screws are appropriate for your project. If not appropriate **DO NOT** use the screws provided. Each project is different so protect your project by measuring before you add the screws.

Remember, the angle of the Side Wall Countertop Support Bracket (left or right) is determined by the front view.

**NOTE:** It is important that the bracket be flush with the cabinet in order for the countertop to sit level & to protect the countertop.

### **Step #3:**

We recommend spacing the brackets 16"-20" apart for maximum countertop protection. If your countertops are larger than the 20" spacing recommendation, then using additional countertop brackets in the middle will help insure your countertop investment.

### **Step #4:**

Once the brackets are secured, place your countertop on top of the brackets & simply caulk around the brackets with clear silicone.

